

Stop operation of thermal oil circulating pump

We would like you to inform precautions about stop operation of thermal oil circulating pump to use our thermal oil heater (HTB type) with safety and security. The details of operation is specified in operation manual. We kindly ask for your confirmation again.

●Requirements for circulating pump stop

- After stopping combustion,

- 1. More than 2 hours are passed.**

- 2. Thermal oil temperature is lower than 100°C.**

Stop circulating pump after confirming the above two points.

(*When pump is stopped without satisfying either requirement, heating tube may be damaged by sudden change of temperature in thermal oil heater.)

●When preventing temperature at loading side from lowering. (after combustion stop)

- By operating manual bypass valve, lowering temperature can be prevented.

- When manual operation for stopping is difficult, option parts can be used. (stop delay timer and etc.)

For the details, contact the nearest MIURA office.

Scan the QR code or click on the following URL for information about our service network.

<https://www.miuraz.co.jp/en/marine/service/network.html>



If you have any questions, please contact nearest MIURA's office.
We hope to receive your continuous support in the future.