

Service News

Vol.58

New maintenance video is now available! ~How to Replace UV Lamp Protective Rubber Ver.3~

We have made a video showing how to replace "protective rubber" that is attached to the UV lamp protective tube of the non-explosion proof UV reactor, one of the components of our ballast water management system.

The video is available on YouTube and can be viewed at the following URL.

We hope you will find this video useful for your maintenance.

【MIURA】How to Replace UV Lamp Protective Rubber ver.3【BWMS HK】

<https://youtu.be/QXbeZXNUOck>



Click here for past videos!

<https://www.youtube.com/playlist?list=PL7mwad6KMEOXpFm2n7D82GFEsw8IPGkwN>

Scan the QR code or click on the following URL for information about our service network.

<https://www.miuraz.co.jp/en/marine/service/network.html>

If you have any questions, please contact the nearest MIURA office.

E mail address: Hakuyo_mka@miuraz.co.jp

